

Follow us on...
 Folgen Sie uns auf ...
 Suis-nous sur...
 Suivez-nous sur
 Seguíci su...
 Síguenos en...
 Siga-nos em...
 Kövessen bennűnket...
 Sekojiet mums...
 想了解更多信息, 请访问.....
 ソーシャルメディア:
 Следите за новостями...

LEGOeducation.com/preschoolsupport



PROFESSIONAL DEVELOPMENT
 BERUFLICHE FORTBILDUNG
 DÉVELOPPEMENT PROFESSIONNEL
 PERFEZIONNEMENT PROFESSIONNEL
 SVILUPPO PROFESSIONALE
 DESARROLLO PROFESIONAL

DESENVOLVIMENTO PROFISSIONAL
 SZAKMAI FEJLŐDÉS
 PROFESIONÁLĀ ATTĪSTĪBA
 专业开发
 開発者用情報
 ПРОФЕССИОНАЛЬНОЕ РАЗВИТИЕ

LEGOeducation.com

LEGO and the LEGO logo are trademarks of the/son des marques de commerce du/son marcas registradas de LEGO Group. ©2019 The LEGO Group. 6259924

LEGO education


CODING EXPRESS	INTRODUCTION GUIDE
DIGI-ZUG	EINFÜHRUNG
L'EXPRESS DU CODAGE	GUIDE D'INTRODUCTION
EXPRESSO DA PROGRAMAÇÃO	GUIDA INTRODUTTIVA
PROGRAM EXPRESSZ	GUÍA DE INTRODUCCIÓN
ĀTRĀ PROGRAMMĒŠANA	GUIA INTRODUTÓRIO
デユプロ® プログラミングトレインセット	BEVEZETŐ ÚTMUTATÓ
ПРОГРАММИРУЕМЫЙ ЭКСПРЕСС	IEVADS
	介绍指南
	導入ガイド
	РУКОВОДСТВО ПО ВНЕДРЕНИЮ

45025





○○○○
○○○○



4 x
1.5V
LR03 (AAA)



○○
○○
○○

On/off	Leslēgt/izslēgt
An/Aus	开/关
Marche/arrêt	Hidup/mati
Encendido/apagado	Buka/Tutup
Ligado/Desligado	オン/オフ
Be/ki	Вкл./выкл.

Motor
Moteur
Motore
Motors
马达
モーター
Мотор



Colour Sensor
Color Sensor
Farbsensor
Capteur de couleur
Capteur de couleurs
Sensore di colore
Sensor de color
Sensor de Cor
Szinérzékelő
Křásu sensors
颜色传感器
Sensor Warna
カラーセンサー
Датчик цвета

Speaker
Lautsprecher
Haut-parleur
Altoparlante
Altavoz
Coluna

Hangszóró
Skalrunis
扬声器
Pembesar Suara
スピーカー
Динамик

Light
Licht
Lumière
Luce
Luz
Fényjelzés

Gaisma
发光
Lampu
ライト
Освещение



○○○○
○○○○



Push-and-Go
Push-And-Go
Pousser pour démarrer
Push-and-Go
Empurrar e Avançar
Told-és-Indul

ledarbināšana piespiežot
推动——让火车自动前行
Tekan-dan-Jalan
Tolak dan Mula
プッシュ&ゴー
Инерционный двигатель

○○
○○
○○



Stop
Anhalten
Arrêt
Parada
Parar
Apstāšanās
Berhenti
停止する
Остановка



Change direction
Ändern der Fahrtrichtung
Changement de direction
Cambia direzione
Cambio de sentido
Mudar a direção
Irányváltás
Kustības virziena maiņa
改变方向
Ubah arah
進行方向を変える
Изменение направления движения



Refuel
Auftanken
Plein
Carburant
Rifornimento
Repostaje
Reabastecer
Üzemanyag feltöltés
Degvielas uzpilde
Isi ulang
Isi Semula
燃料を入れる
Заправка



Light on/off
Licht ein/aus
Lumière allumée/éteinte
Luce accesa/spenta
Luz
Luz ligar/desligar
Világítás ki/be
Gaismu ieslēgšana/izslēgšana
灯光开/关
Lampu hidup/mati
ライト オン/オフ
Включение/выключение света



Sound
Geräusche
Son
Suono
Sonido
Som
Hang
Skapa
声音
Suara
Bunyi
サウンド
Сигнал

LEGOeducation.com/preschoolsupport

Less challenging
Weniger anspruchsvoll
Moins difficile
Meno impegnativo
Más sencillo
Menor desafio
Könnyebb feladat
Zema sarežģītības pakāpe
较低难度
難易度低め
Менее сложные



More challenging
Anspruchsvoller
Plus difficile
Più impegnativo
Más complicado
Maior desafio
Nehezebb feladat
Augsta sarežģītības pakāpe
较高难度
難易度高め
Более сложные



○○○○
○○○○



○○○○
○○○○

Teaching Material
Lehrmaterial
Supports pédagogiques
Matériel didactico
Materiale didattico
Material didáctico
Material de Ensino
Oktatási anyagok
Mācību materiāls
教材
Учебные материалы

LEGOeducation.com/preschoolsupport